


*KEY OPTION LIST


R608	BAND	FREQUENCY RANGE	STEP
TIN WIRE	FM	87.5-108.0MHz	100K
	AM	520-1710KHz	10K
6.8K	FM	87.5-108.0MHz	100K
	AM	522-1620KHz	9K
15K	FM	87.50-108.00MHz	50K
	MW	522-1620KHz	9K
27K	FM	87.5-108.0MHz	100K
	MW	520-1710KHz	10K
	SW	5900-18000KHz	5K
47K	FM	87.50-108.00MHz	50K
	MW	522-1620KHz	9K
	SW	5900-18000KHz	5K
150K	FM1	65.00-74.00MHz	10K
	FM2	87.50-108.00MHz	50K
	AM	522-1620KHz	9K

R609	HOUR
TIN WIRE	12H
220K	24H



* FUNCTION LOGIC LIST

FUNCTION	F0	F1	F2	NO PLAY
CD	1	1	0	
TUNER	1	0	1	
TAPE	0	1	1	0 0 0



*():CD-680AX